

## WIRES TO MOVE

MOVE	BA	A2	GREEN	BF	C4	SOLENOID 6	
MOVE	BA	A17	PINK/BLACK	BF	C5	SOLENOID 3	
MOVE	BA	A18	LIGHT GREEN	BF	C6	SOLENOID 4	
MOVE	BA	A19	BLACK/WHITE	BF	C9	SOLENOID 1	
MOVE	BA	A20	BLUE	BF	C10	SOLENOID 2	
MOVE	BA	A43	LIGHT GREEN	BF	C22	LOCKUP SOLENOID 7	
MOVE	BA	A37	ORANGE/BLACK	BF	C8	TRANS TEMP	
MOVE	BA	A39	BROWN	BF	C29	SOLENOID 5	
JOIN	BA	A32	GREY	BF	C16	TRANS TEMP SENSOR SIG RTN	TRANS WIRING HARNESS
MOVE	BA	B28	BROWN	BF	B45	BROWN/WHITE	VREF 2
JOIN	BA	B29	BLACK	BF	B33	GREY/RED	SIG RTN2